



46R-5000C
Revised October, 1996

OPERATION AND MAINTENANCE MANUAL

**BYPASS/
ISOLATION
DELAYED
TRANSITION
TRANSFER SWITCH**

**ZBTSDH SERIES
100 THRU 400 AMPS**

MODEL NUMBER

SERIAL NUMBER

TABLE OF CONTENTS

Storage, Installation	1
Cabinet (exterior, front view)	2
Parts list (electrical)	3
Top and lower panels, front view. Switch details	4
Bypass and ATS Power Panels — Parts list	5
Bypass and ATS Control Panel Layout	6
Bypass and ATS Control Panel — Parts list	7
Operation of Bypass/Isolation Switch	8
Definitions and Operation Notes	9
ZBTSDH Operation, Maintenance	10, 11
ARSM and Timer Adj., Lubrication	12
Torque Requirements	13
Cabinet Dimensions	14
Control Disconnect Plugs	15
Field Notes	16
Bypass Control Panel Schematic Drawing	17
Typical Bypass and ATS Schematic Drawing	18

STORAGE:

The ZBTSDH should be stored in a clean dry area. AVOID STORAGE BENEATH STEAM OR WATER PIPES. Excessive moisture may damage the unit. The switch should only be stored on a level (horizontal) surface.

INSTALLATION:

1. Lifting:

To lift and maneuver the Bypass Switch use lifting angles. See Fig. 1 (below). CAUTION: Depending upon the model, a ZBTSDH weighs between 700—750 lbs. Use adequate machinery and cables to handle the load.

2. Equipment Preparation:

- a). Check nameplate to assure switch system voltage and amperage is correct. Any discrepancy should be immediately reported to a Zenith representative.
- b). Lock open breakers to normal and emergency lines.

3. Cabinet Preparation:


- a). A small amount of cabinet work is required before the cables are connected. **Cover the switch and the controls to avoid metal fragments from entering mechanical and electrical components.** Visually verify that metal filings are removed from top bus support. (Use vacuum if necessary).
- b). Standard cable entry is through the top or bottom of the cabinet. Fig. 2 below shows one suggested knockout order. For a guide to assist in the hole layout, refer to page 15.

4. Cable and Wire Connections:

- a). To remove possible oxide, clean cable conductor with a wire brush and apply a contact oxide inhibitor. Insert cables into appropriate lugs.
- b). Connect all auxiliary wires for external electrical operation. Example: E-start, remote alarm lights or buzzers, motor control contacts, etc. Allow enough slack in wires to allow movement of the ATS to isolate position (approx. 1 ft.).


5. Prior to the Unit's Energization:

- a). Remove any debris incurred due to installation (cut cable strands, metal filings, etc.).
- b). Inspect the unit and verify torque of cable and wire connections.



Note: When lifting the switch, a spreader must be used. The height H must be equal to D/2.

FIG. 1




TYPICAL LAYOUT

FIG. 2

INSTRUCTION
NAMEPLATE

MANUAL
BYPASS
HANDLE (MBH)





LBE
LEA
LNA
LBN
LAI
LAT
LDS
LIT

L2
L1
TS

A. CABINET ELECTRICAL PARTS

TAG	DESCRIPTION	PART NUMBER
LNA LEA LBN LBE LAT LAI LIT LDS	Normal Available Indicator (G) Emergency Available Indicator (R) Bypass Normal Location Indicator (G) Bypass Emergency Location Indicator (R) ATS Test Position Indicator (A) ATS Isolate Position Indicator (A) ATS Inhibit Indicator (R) ATS Disconnect Switch "Off" Indicator (R) Flashing Bulb	PS-1272
	COMMON PARTS BYPASS INDICATORS	
	Bulb Socket Red Lens (R) Green Lens (G) Amber Lens (A)	Y500005 PS-5046 PS-5047 PS-5048 PS-5049
L1 L2	ATS Emergency Position Indicator ATS Normal Position Indicator Green Lens (Normal) Red Lens (Emergency) Bulb Socket Normal/ Emergency Nameplate Emergency Bulb Normal Bulb	PS-5048 PS-5047 PS-5046 V-1502 PS-5105 PS-5105
TS	Test Switch Operator, Momentary Contact Block N.C. Name Plate Contact Mounting Base	L-1025 L-1029 V-1503 PS-3473




SWITCH DETAILS

B. BP-BYPASS AND ATS AUTOMATIC TRANSFER SWITCH POWER PANEL

TAG	DESCRIPTION		PART NUMBER BY AMPERAGE				
			100	150	225	260	400
N1, 2, 3, N E1, 2, 3, N T1, 2, 3, N	Normal Emergency Load	} LUGS	PS-4418	PS-4418	PS-4418	S-1422	S-1422
BYPASS	Contact Assembly		(Movable & Stationary for 3 Pole Units)				
N1, 2, 3	Normal		46P-1104A	46P-1104B	46P-1104C	46P-1104D	46P-1104E
N	(Sw. Neut. Norm.)		46P-1105A	46P-1105B	46P-1105C	46P-1105D	46P-1105E
E1, 2, 3	Emergency		46P-1106A	46P-1106B	46P-1106C	46P-1106D	46P-1106E
N	(Sw. Neut. Emerg.)		46P-1107A	46P-1107B	46P-1107C	46P-1107D	46P-1107E
ATS	Contact Assembly		(Movable & Stationary for 3 Pole Units)				
NL1, 2, 3	Normal		46P-1100A	46P-1100B	46P-1100C	46P-1100D	46P-1100E
N	(Sw. Neut. Norm)		46P-1101A	46P-1101B	46P-1101C	46P-1101D	46P-1101E
EL1, 2, 3	Emergency		46P-1102A	46P-1102B	46P-1102C	46P-1102D	46P-1102E
N	(Sw. Neut. Emerg.)		46P-1103A	46P-1103B	46P-1103C	46P-1103D	46P-1103E
Arc Grid Assy.			46P-1099				
XBN, XBE	Bypass Step-Down Transformer 25VA Secondary 24V	VOLTAGE	PART NO.				
		120/240	K-3061				
		208/416	K-3063				
		220/440	K-3064				
		240/480	K-3062				
		380	K-3067				
		575	K-3065				
		600	K-3066				
CN/O CE/O	Main ATS Operating Coils						
	Voltage Systems						
	No.	Volts	Ph	Wire	Coil Volts	Poles	PART NO.
	-1	120	1	2	120	2	K-2178
	-2	120/240	1	3	240	2,3	K-2189
	-3	240	3	3	240	3	K-2189
	-38	120/240	3	4	240	3,4	K-2189
	-4	120/208	3	4	208	3,4	K-2177
	-5	480	3	3	480	3	K-2176
	-6	575/600	3	3	575/600	3	SPO
-7	277/480	3	4	480	3,4	K-2176	
-9	240/416	3	4	416	3,4	SPO	
-91	220/380	3	4	380	3,4	K-2188	
SN/O	CN/O Limit Switches						L-3080
SE/O	CE/O Limit Switches						
A3	ATS Emergency Position Switch						
A4	ATS Normal Position Switch						
SCN/O,SCE/O	CN/O, CE/O Limit Switches						L-3079 (Detail 2a)
AA AE1, 2 PLS1, 2	ATS Auto Location Switch ATS Isolate/Remove Location Switch Position Lever Switch						L-3071 (Detail 2b)
AI AT1, 2	ATS Isolate Location Switch ATS Test Location Switch						L-3070 (Detail 2c)
AB3/ABE AB4/ABN NA4 EA3	Bypass Emergency Position Switch Bypass Normal Position Switch Normal TRS Limit Switch Emergency TRS Limit Switch						L-5021 (Detail 2d)
BTE BTN TSE BLL ALL	Bypass Emergency Position Switch Bypass Normal Position Switch ATS Engaged Switch Bypass Lock Location Switch ATS Lock Location Switch						L-3054 (Detail 2e)
DS	ATS Solenoid Disconnect Switch Operator 2-Position Maintain Contact Block N.C. (1) Contact Block N.O. (2) Contact Block Mounting Plate						L-4018 L-1029 L-1028 PS-3473
BPS TRS	Bypass Interlock Solenoid Transfer Release Solenoid						K-2180 K-2180

C. BYPASS CONTROL PANEL



D. ATS CONTROL PANEL (SSRCP)

TO POWER PANEL




CHART 1

Jumper	Connects Points	Remove When Accessories Used
J1	23, 23A	B1
J2	23A, 23B	B2
J3	23B, 23C	B3
J4	23C, 23Z	JIN, TS, C/D
J5	23Z, 27	T, YN
J6	25, 25Z	T3, R4
J7	28, 28Z	SI, C, C/D
J8	28Z, 29	PI & U
J9	33A, 33Y	ER1, 2, 3, J1E
J10	33Z, 37	W
J11	35, 35Z	R4, W3

C. BYPASS CONTROL PANEL (46P-1079) INCLUDES PARTS BELOW

TAG	DESCRIPTION	PART NUMBER
BR1, 2, 3	Bridge Rectifier	PS-5076
RNH	Normal Voltage Relay	Y260000
R1	Resistor RNH, 30 ohm	PS-4056
R2	Resistor LDS, 120 ohm	PS-4057
D1	Diode	PS-4812
CA	Capacitor RNH	PS-4058
ATR	Auxiliary Test Relay	Y260000

D. ATS CONTROL PANEL (SSRCP) STANDARD ITEMS

TAG	DESCRIPTION	VOLTAGE 50/60 HZ	PART NO.
XN, XE	Control Transformers (See Note 1)	120V	K-3076
		208V	K-3070
		240 or 480V	K-3071
		416V	K-3089
B-1, 2, 3	Phase Relays Solid State (See Note 1)	120V	K-1185
		208 or 240V	K-1186
		480V	K-1188
VFSM	Voltage Frequency Sensor	120V	K-1192
CR	Control Relay	120V	K-1204
RT	Bypass T Relay	120V	K-1204
CN1,CN0,CE1,CE0	CN/O,CE/O Transfer Relays (not shown)	120V	K-1120
J1-J11	Jumpers		PS-5067
DT	Time Delay Neutral to Normal	120V	OSA-A-T
DW	Time Delay Neutral to Emergency	120V	OSA-A-T

(OPTIONAL ITEMS)

TAG	DESCRIPTION	VOLTAGE	PART NUMBER
T	Time Delay to Normal, Timer Solid State	120V .1 Sec. to 9990 Hrs. (Adj.)	OSA-A-T
U	Engine Cool Down, Timer Solid State	120V .1 Sec. to 9990 Hrs. (Adj.)	OSA-A-U
W	Time Delay Emergency, Timer Solid State	120V .1 Sec. to 9990 Hrs. (Adj.)	OSA-A-W
PI	Time Delay Engine Start, Timer	120V (.5 to 6 sec. Adjustable)	K-1201
P2	Optional (Mounted below SSRCP)	120V (300 Sec. Adjustable)	K-1061

Notes:

1. If -6 voltage system (575/600V) is supplied, then XN, XE is K-3087 and B1,2, 3 is K-1185 (120V) supplied with XB (575:600V/120V) 3 phase transformer assembly. B1, 2, 3 mounted below SSRCP.

BYPASS/ISOLATION SWITCH OPERATION

BP — Bypass Switch, Indicated by Contacts BN/BE, is a 3 Position Switch
 ATS — Automatic Transfer Switch

1. Automatic

1. Manually operated Bypass Switch contacts (BN/BE) are open and the ATS is supplying the load. (Fig. 1).
2. Disconnect Switch (DS) is in "Auto" position.




FIG. 1 BP IS OPEN WITH ATS IN NORMAL POSITION.

2. To Bypass ATS

1. Open bottom cabinet door and turn DS to "Inhibit".
2. Position Manual Bypass Handle (MBH) to same power source as ATS (Fig. 2).




FIG. 2 BP IS BYPASS NORMAL WITH ATS IN NORMAL POSITION.

3. To Test ATS

1. Bypass per above instructions.
2. Move ATS Location Handle (ALH) to "Test" location.
3. Turn DS to "Auto".
4. Test Switch (TS) on bottom cabinet door will allow electrical testing of ATS. (Fig. 3).




FIG. 3 BP IS BYPASS NORMAL WITH ATS IN TEST LOCATION. (ATS LOAD CONNECTION IS OPEN)

4. To Isolate ATS

1. Bypass per above instructions.
2. Move ALH to "Isolate" location.




FIG. 4 BP IS BYPASS NORMAL WITH ATS IN ISOLATE LOCATION.

5. To Remove ATS

1. Bypass and Isolate per above instructions.
2. Move ALH to "Release" location.
3. Disconnect multi-pin plugs and external connections.
4. Lift ATS out of drawer.

6. To Reconnect ATS

1. Place ATS into drawer slots, (front rollers first).
2. Turn DS to "Inhibit" position.
3. Position ATS to same source as Bypass Switch.
4. Reconnect Multi-pin plugs and external connections.
5. Push ATS inward to engage carriage.
6. Move ALH to "Test" location (as indicated by light).
7. Turn DS to "Auto" position and use TS to electrically operate ATS.
8. Turn DS to "Inhibit" position.

9. Move ALH to "Auto" location.
10. Turn DS to "Auto" and position MBH to "Open".
11. ATS now fully automatic (Fig. 1).

7. Notes

1. DS in "Inhibit" position will prevent ATS electrical operation.
2. Do not use excessive force on mechanical handles (interlocks prevent incorrect sequencing).
3. When ATS is in Test or Isolate, Bypass Switch is a manual transfer switch to either available power source.
4. To operate Bypass Switch when ATS is in Test or Isolate, position MBH to available power source (indicated on light panel).
5. Above figures depict Bypass Normal; sequence is same for Bypass Emergency.

DEFINITIONS:

BP — Bypass/Isolation Switch

It is a manually operated device used in conjunction with an Automatic Transfer Switch (ATS) to provide a means of directly connecting load conductors to a power source, and of disconnecting the Automatic Transfer Switch.

The BP can also be used as a Manual Transfer Switch in the event of a power failure while the ATS is in the TEST, ISOLATE, or RELEASE positions.

ATS — Automatic Transfer Switch

Is a self-acting equipment for transferring one or more load conductor connections from one power source to another.

DS — Disconnect Switch

Inhibits operation of ATS main coils (CN/O,CE/O). In the "AUTO" position, the ATS operates normally. In the "INHIBIT" position the main coils(CN/O,CE/O) cannot be energized, and automatic transfer in either direction cannot take place.

MBH — Manual Bypass Handle

Actuates the Bypass Operator.
Center for Bypass Open.
Down for Normal Bypass.
Up for Emergency Bypass.

TS — Test Switch

Simulates Normal line failure when open.

OPERATION NOTES:

1. The ATS will not operate if:
 - a). Harness plugs are not connected.
 - b). DS is in the 'INHIBIT' position.
 - c). ATS is not in 'AUTO' or 'TEST' location.
 - d). ATS is in 'AUTO' location and BYPASS SWITCH is not open.
2. The MBH will not operate if:
 - a). ALH is not engaged in one of the following: AUTO — TEST — ISOLATE.
 - b). If source selected is opposite of the ATS position while in the AUTO location.
 - c). ATS is in 'TEST' or 'ISOLATE' location and source selected is not available.
3. The ALH (ATS Location Handle) will not operate if:
 - a). BP and ATS are not positioned to same source.
 - b). Power is not available.
 - c). Harness Plugs are not connected.
 - d). ATS has reached limit of travel to 'AUTO' or 'ISOLATE'.

**READ THE FOLLOWING PARAGRAPHS BEFORE PROCEEDING TO "TEST PROCEDURE".
(THIS PROCEDURE IS ONLY TO BE PERFORMED BY AUTHORIZED PERSONNEL)**

CAUTION:

Loads controlled by Bypass/Isolation Transfer Switch may cause PERSONAL INJURY by UNAUTHORIZED PERSONNEL operating or testing this equipment.

Check all wiring diagrams that have been supplied for added options that may affect external equipment: For example; Starting and Stopping of Elevators and Motors.

A 'Control Panel Test' or a test with the ATS in the TEST LOCATION runs the EMERGENCY SOURCE with no load. A no load operation may be detrimental to the engine, and the Engine/Generator Manufacturer should be consulted.

Allow sufficient time on the U timer for engine to safely cool down.

RECOMMENDED TIMER SETTINGS:

T — Restoration to Normal.....30 minutes (Factory set)
U — Engine Cooldown/Stop5 minutes (Factory set)
W— Engine Warmup5 seconds (Factory set)
P1—Engine Start3 seconds (Factory set)

TEST PROCEDURE

The ATS can be tested in either of two locations:

- 1). AUTO LOCATION
- 2). TEST LOCATION

1. "AUTO LOCATION":

Full Transfer Test - This test checks the complete operation of the ATS by transferring an interrupting the load's power source from "Normal" to "Emergency"

Depress TS (Test Switch): First the generator starts, then the "W" timer times out (timer will indicate ON). The ATS will open. After the "DW" timer times out, the ATS will transfer to Emergency. Engine/Generator will shut down after timer "U" times out. Full Transfer Test is now complete.

2. "TEST LOCATION":

This procedure is recommended for Preventative Maintenance (PM) of the ATS without interrupting the load thru the BYPASS/ISOLATION SWITCH. Refer to Page 8(step 3).

NOTE: TEST LOCATION is recommended after maintenance of ATS.

OPERATION OF AUTOMATIC TRANSFER SWITCH

When the normal line (NL) falls to the preset dropout point, or if any normal phase fails, the phase relay(s) will drop out disconnecting the CR relay. P1 drops out after .5 to 6 seconds (adjustable) and signals the generator to start.

When emergency line (EL) voltage and frequency reach at least 90% of rated value, the VFMS relay is energized. The RT relay is now energized to operate the CNO relay thru the SE cutout switch causing the main transfer coil CN/O to operate thru the SCNO limit switch. The load is now transferred to the Open position. The SNO and SCNO limit switches operate to disconnect the CNO relay and CN/O transfer coil. The transfer switch is now locked mechanically Open. SNO now is deactivated. This energizes the DW timer. After time setting has lapsed, DW will energize CE1, which will energize main transfer coil thru SCE and CE1. The load is now transferred to the Emergency line supply. The SE and SCE limit switches operate to disconnect the CE1 relay and CE/O main transfer coil. The transfer switch is now locked mechanically in Emergency position.

When the normal line voltage restores to the preset value, the phase relay(s), (B1,2,3) operate to energize the normal restoration timer T. After the time setting has lapsed, the timer contact closes to energize CR relay. The CEO relay is now energized thru the SN and SEO limit switches, causing the main transfer coil CEO to operate thru the SCEO limit switch. The load is now transferred back to the Open position. The SEO and SCEO limit switches operate to disconnect the CEO relay and CE/O transfer coil. The transfer is now locked mechanically Open. SEO is now activated, energizing DT timer. After time setting has lapsed, DT will energize CN1 which will energize main transfer coil thru CN1 and SCN. The load is now transferred to the Normal line supply. The SN and SCN limit switches operate to disconnect the CN1 relay and CN/O main transfer coil. The transfer switch is now locked mechanically into Normal position.

MAINTENANCE

Electrical Test:

The ATS may be electrically tested for preventive maintenance (refer to page 10 "Test Procedure"). After completion of an electrical test, the ATS should be returned to the Auto Operation Mode.


Inspection:

CONTACTS — The movable and stationary contacts are a vital part of the and must be kept clean. To inspect the ATS contacts, place ATS in Isolate location (see page 8). Examine the contacts.

Any surface deposits must be removed with a clean cloth (DO NOT USE EMERY CLOTH OR A FILE).

After the movable and stationary contacts are wiped clean (no discoloration or deposits), return the to Auto Mode.

CURRENT CARRYING PARTS — An easily detected but abnormal condition is the discoloration of current carrying parts (particularly copper). Discoloration appears as darkened materials or finishes. Any discolored parts should be cleaned. **WARNING: ANY MAINTENANCE SHOULD ONLY BE DONE WHILE THE POWER IS OFF!** If the discoloration persists, contact the factory.




New Solid State Time Delay

Accessories T, U, W Solid State Timers Adjustable in Seconds, Minutes and Hours (Plug-In Style).

To select a time unit, operate the pushbuttons of the rightmost thumbwheel switch until the desired time unit is shown in window. The time unit can be selected by pushing the plus (+) bottom button or the minus (-) top button. The desired time is specified by operating the three thumbwheel switches in the middle of the front panel.

Setting of the timer at 000 will result in an infinite delay. The min. setting for OSA-A timers is $\frac{1}{10}$ of 1 second as shown. See instructions.

0	0	1	0.1 Sec.
---	---	---	-------------



Close Differential (ARSM) Relay Adjustment

The voltage points at which the relay operates are adjustable. When the relay pulls in, an audible click is heard, and the LED will come on.

Setting the Relay:

If the relay should be set with a variable voltage supply (Variac):

1. Turn pick-up control fully clockwise.
2. Turn drop-out control fully counterclockwise.
3. Set Variac pick-up voltage to desired level.
4. **Very slowly** rotate pick-up adjustment counterclockwise until relay picks up. (LED will energize).
5. Set Variac drop-out voltage to desired level.
6. **Very slowly** rotate drop-out adjustment clockwise until relay drops out (LED de-energizes).

Verify settings by raising voltage until relay picks up, then lower voltage until relay drops out, making sure that relay operates at desired voltage levels.

LUBRICATION

The cams of the ZBTS DH are lubricated with Super Lube PTFE grease, and gears with Dow Chemicals "Molykote" (321R or GN paste). These lubricants provide adequate lubrication for a clean and properly maintained switch's lifetime. Should debris contaminate the mechanism, clean and apply additional lubricants. Mobiltemp SHC-32 is used on isolating contacts.

LUBRICATION MAINTENANCE CHART

Date Inspected	Date Lubricated	Lubricant Used (Cams) (Gears)	Notes

TORQUE REQUIREMENTS FOR FIELD CONNECTIONS

NOTICE TIGHTENING TORQUES FOR FIELD WIRING TERMINALS

Socket Size Across Flats, Inch	Tightening Torque Pound-Inches
1/8	45
5/32	100
3/16	120
7/32	150
1/4	200
5/16	275
3/8	375
1/2	500
9/16	600

TORQUE REQUIREMENTS FOR ELECTRICAL CONNECTIONS

All current carrying parts use compression washers and should be torqued to the values presented below.
Caution: DO NOT OVERTORQUE WASHERS; follow the given torque values.

TORQUE REQUIREMENTS (inch - lb. except denoted by + are ft. - lb.)



BOLT SIZE	GRADE 5	SOCKET HEAD	SET SCREW	COMPRESSION WASHERS	
				1	2
1/4 - 20	75	120	52	80	87
5/16 - 18	157	225	105	159	170
3/8 - 16	+23	412	165	+23	+26
1/2 - 13	+57	1030	386	+56	+59

WIRE CONNECTION TIGHTENING TORQUE

WIRE COND. SIZE AWG or MM	SCREW DRIVER TORQUE (inch - lb.)
18 - 16 AWG	19
14 - 8	19
6 - 4	36

LUG BOLTING TORQUE



BOLT DIA. (inch)	TORQUE (ft. - lb.)
1/4 OR LESS	6
5/16	11
3/8	19
7/16	30
1/2	40
5/8 OR MORE	55



3 POLE

- NOTES:
1. TYPE 1 ENCLOSURE.
 2. ALL DIM. ± 1/8.
 3. "WBR" WIRE BENDING RADIUS.

ZBTS DH	CABINET #	A	B	C	D	E	F	G
10-22 (3P)	F-1310	79	42 9/16	30	21 1/2	72	15 1/4	21 1/2
26-40 (3P)								




4 POLE


- NOTES:
1. TYPE 1 ENCLOSURE.
 2. ALL DIM. ± 1/8.
 3. "WBR" WIRE BENDING RADIUS.

ZBTS DH	CABINET #	A	B	C	D	E	F	G
10-22 (4P)	F-1311	79	42 8/16	36	23 7/8	72	15 1/4	21 1/2
26-40 (4P)								

DISCONNECT PLUGS ZBTSDH 100-400 AMPS




BYPASS CONTROL SCHEMATIC



- LNA - NORMAL AVAILABLE LIGHT
- LEA - EMERGENCY AVAILABLE LIGHT
- RNH - NORMALLY HELD RELAY
- D1 - DIODE
- R1 - RESISTOR, RNH
- C - CAPACITOR, RNH
- BR-1,2,3 - BRIDGE RECTIFIER
- AA-1 - LIMIT SWITCH, ATS AUTO LOCATION
- BTN - LIMIT SWITCH, BYPASS TRANSFER NORMAL (MBH MOVEMENT TO NORMAL)
- BTE - LIMIT SWITCH, BYPASS TRANSFER EMERG. (MBH MOVEMENT TO EMERGENCY)
- BPS - BYPASS SOLENOID
- AA-2 - LIMIT SWITCH, ATS AUTO LOCATION
- ALL - LIMIT SWITCH, ATS LOCK LOCATION
- AT-2 - LIMIT SWITCH, ATS TEST LOCATION
- LAT - LIGHT, ATS TEST LOCATION
- AI - LIMIT SWITCH, ATS ISOLATE LOCATION
- LAI - LIGHT, ATS ISOLATE LOCATION
- BLL - LIMIT SWITCH, BYPASS LOCK LOCATION
- PLS-1 - PERMISSIVE LIMIT SWITCH
- TSE - LIMIT SWITCH, TRANSFER SWITCH ENGAGED
- TRS - SOLENOID, TRANSFER RELEASE
- NA-4 - LIMIT SWITCH, ATS IN NORMAL
- EA-3 - LIMIT SWITCH, ATS IN EMERGENCY
- LBE - LIGHT, BYPASS EMERGENCY
- LBN - LIGHT, BYPASS NORMAL
- AB4 - LIMIT SWITCH, BYPASS NORMAL
- AB3-1 - LIMIT SWITCH, BYPASS EMERGENCY
- PLS-2 - PERMISSIVE LIMIT SWITCH
- ATR - AUTO/TEST RELAY
- AT-1 - LIMIT SWITCH, ATS TEST LOCATION
- LIT - LIGHT, ATS INHIBIT
- DS - ATS DISCONNECT SWITCH
- R2 - RESISTOR, LDS
- LDS - LIGHT, DISCONNECT SWITCH INHIBIT POSITION
- ALH - ATS LOCATION HANDLE

ENGINE START CIRCUIT

- AE-1,2 - LIMIT SWITCH, ENGINE START TRANSFER
- AB3-2,3 - LIMIT SWITCH, BYPASS EMERGENCY



LIMIT SWITCH CHART

X = ACTUATED	ATS LOCATION		ATS MODE		BYPASS MODE	
	AUTO	TEST	ISO	REMOVE	NORM. EMERG.	NORM. EMERG. OPEN
AA-1,2	X					
AT-1,2		X				
AI			X	X		
ALL	X	X	X	X		
TSE	X	X	X			
AE-1,2			X	X		
NA-4					X	
EA-3						X
AB4						X
AB3-1,2,3						X
BLL					X	X
PLS-1,2	ACTIVATED WHEN ALH IS OPERATED					

PERMIT CIRCUITS





NORMAL TRANSFER PERMIT CIRCUIT IN AUTO AND TEST POSITIONS



EMERGENCY TRANSFER PERMIT CIRCUIT IN AUTO AND TEST POSITIONS

LIMIT SWITCHES




NL1,2,3,NN - NORMAL SOURCE


T1,2,3,TN - LOAD

EL1,2,3,EN - EMERGENCY SOURCE

VOLTS	NO OF PHASES	NO OF WIRES
3 120/240	1 3	1 4
4 120/208	1 3	1 4
5 480	1 3	1 3
7 127/480	1 3	1 4
8 240/416	1 3	1 4
38 120/240	1 3	1 4



- EN SWITCHED NEUTRAL OR SOLID NEUTRAL IF REQUIRED
- DS - DISCONNECT SWITCH FOR SERVICE
- CNO - NORMAL OPERATING COIL
- SCN } CN/O CUTOUT SWITCH
- SCNO }
- A3 - MECHANICALLY ACTUATED AUX. CONTACTS (EMERGENCY POSITION)
- A4 - MECHANICALLY ACTUATED AUX. CONTACTS (NORMAL POSITION)
- CE/O EMERGENCY OPERATING COIL
- SCE } CE/O CUTOUT SWITCH
- SCEO }
- B1,2,3 - UNDER VOLTAGE SENSING RELAY, 27
- XN - NORMAL CONTROL TRANSFORMER
- XE - EMERG. CONTROL TRANSFORMER.




- TS - TEST SWITCH STIMULATING NORMAL LINE FAILURE
- T - TIME DELAY ON RETRANSFER
- CR - CONTROL RELAY, 27, 32, 36, 41
- YN - PUSH BUTTON TO BYPASS T
- SN } MECHANICALLY ACTUATED CONTACTS
- SNO } (NORMAL POSITION)
- CEO - CONTROL RELAY, ENERGIZES CE/O SOLENOID OPENING EMERGENCY, 15,
- DT - TIME DELAY IN NEUTRAL TO NORMAL, 34
- CNI - CONTROL RELAY, ENERGIZES CN SOLENOID CLOSING NORMAL, 10, 13
- L2 - NORMAL POSITION LIGHT
- U - ENGINE OVER-RUN TIMER, 37
- PI - TIME DELAY TO ENGINE START, 38, 50
- VFSM - EMERGENCY VOLTAGE AND FREQUENCY SENSING RELAY, 41
- W - TIME DELAY ON RETRANSFER, 42
- RT - BYPASS T CONTACT UPON EMERG. FAILURE, 29, 43, 45, 49
- SE } MECHANICALLY ACTUATED CONTACTS
- SEO } (EMERGENCY POSITION)
- CNO - CONTROL RELAY, ENERGIZES CN/O SOLENOID OPENING NORMAL, 10, 13
- DW - TIME DELAY IN NEUT. TO EMERG., 46
- CEI - CONTROL RELAY, ENERGIZES CE SOLENOID CLOSING EMERGENCY, 15, 18
- LI - EMERGENCY POSITION LIGHT

49. LEGEND:

- 50 - WIRE CONNECTION
- 51 - WIRE ON MAIN TERMINAL BLOCK
- 52 - WIRE ON DISCONNECT PLUG.

ENG. START CONTACT FROM PI



BYPASS & ATS SCHEMATIC



830 West 40th Street
Chicago, IL 60609 USA

Phone: 773 247-6400
FAX: 773 247-7805