

GE Energy  
Energy Management



## MTDIN Series Instruction manual



CONTENTS

1	BASIC INSTRUCTIONS.....	3
1.1	Checks on receipt.....	3
1.2	Main features.....	3
1.3	Electrical parameters.....	3
1.4	Other features.....	4
1.5	Available models.....	4
2	INSTALLATION AND START-UP.....	5
2.1	Installation.....	5
2.1.1	Power supply voltage.....	5
2.1.2	Maximum voltage in the voltage measurement circuit.....	5
2.1.3	Maximum permanent current in the current circuit.....	5
2.1.4	Transistor output features.....	5
2.1.5	Temperature probe features.....	5
2.1.6	Operating conditions.....	5
2.1.7	Safety.....	6
2.2	Start-up.....	6
2.2.1	Description of terminals.....	6
2.2.2	Connection diagrams.....	7
3	OPERATING MODE.....	8
3.1	Keypad.....	8
3.2	Default settings.....	9
3.2.1	Default display.....	9
3.2.2	LED Indicators.....	10
4	SETTING SET-UP.....	11
4.1	Measurement Set-up.....	11
4.1.1	Transformation Ratios.....	12
4.1.1.1	Voltage primary value.....	12
4.1.1.2	Voltage secondary value.....	12
4.1.1.3	Current primary value.....	12
4.1.1.4	Current secondary value.....	13
4.1.2	Measurement in 2 or 4 quadrants.....	13
4.1.3	Power demand meter.....	14
4.1.3.1	Integrated parameter.....	14
4.1.3.2	Integration period.....	14
4.1.3.3	Clearing power demand meter value.....	15
4.1.4	Display and backlight.....	15
4.1.4.1	Selection of screens to be displayed.....	15
4.1.4.2	Selection of start page.....	15
4.1.4.3	Backlight (Backlit display).....	16
4.1.5	Clearing energy meter values.....	16
4.1.6	Setting THD or D.....	16
4.1.7	Digital output for the transistor.....	16
4.1.7.1	Impulse per n KW-h or Kvar-h consumed or generated.....	16
4.1.7.2	Alarm condition.....	17
4.2	Communication Set-up.....	19
4.2.1	Default settings.....	20
4.2.2	Peripheral number.....	20
4.2.3	Transmission speed.....	21
4.2.4	Parity.....	21
4.2.5	Data bits.....	21
4.2.6	Protection of data Set-up using password.....	22
5	APPENDIX – MTDIN-COM SERIES.....	23
6	MODBUS RTU PROTOCOL.....	24
6.1	MODBUS memory map.....	24
6.2	RS-485 Connection diagram.....	27



## 1 BASIC INSTRUCTIONS

This manual is designed to familiarize the user with operating the MTDIN Power analyzer in order to get the best from its features.

### 1.1 Checks on receipt.

Please check the following when receiving the analyzer:

- The equipment delivered matches your order specifications.
- Check that the equipment has not been damaged during delivery.
- Check that it has the correct instruction manual.



This manual contains information and warnings about the **MTDIN Power analyzer** which must be followed to guarantee the proper operation of all instrument functions and to maintain it in a safe condition. Installation and maintenance for this analyzer should be carried out by a qualified person.

### 1.2 Main features

The **MTDIN** Power analyzer is a programmable measuring instrument; it offers a series of operating options, which may be selected from configuration menus on the instrument itself. Before starting the analyzer carefully read sections: power supply, connection and setting and select the most suitable form of operation in order to obtain the required data.

The **MTDIN** measures, calculates and displays the main electrical parameters for three-phase, balanced or unbalanced industrial systems. Measurements are taken in true effective value using the three phase and neutral voltage inputs and three current inputs to measure  $I_N/1A$  or  $I_N/5A$  secondaries from external measurement transformers.

Figure 1. [MTDIN]



The **MTDIN** displays all electrical parameters through its backlit LCD display. Three instantaneous values, maximum or minimum can be seen on each page.

### 1.3 Electrical parameters

By using its internal processor, the **MTDIN** shows on the screen and through communication (according to model), over 100 parameters, which may be either single-phase or three-phase. These parameters may or may not be displayed on the screen, according to the equipment's preset values.

PARAMETER	UNIT	L1	L2	L3	III
Phase-neutral voltage	$V_{f-n}$	•	•	•	
Phase-phase voltage	$V_{f-f}$	•	•	•	
Current	$A$	•	•	•	••
Frequency	$Hz$	•			
Active power	$kW$	•	•	•	•
Reactive power L	$kvarL$	•	•	•	•
Reactive power C	$kvarC$	•	•	•	•
Apparent power	$kVA$	•	•	•	•
Power factor	$PF$	•	•	•	•
$\cos \varphi$	$\cos \varphi$				•
Maximum demand	$Pd$	•	•	•	•
Neutral current	$I_N$			•	
Voltage THD	$\% THD - V$	•	•	•	
Current THD	$\% THD - A$	•	•	•	
kWh (consumption and generation)	$W \cdot h$				•
kvarh.L (consumption and generation)	$W \cdot h$				•
kvarh.C (consumption and generation)	$W \cdot h$				•
kVAh (consumption and generation)	$W \cdot h$				•
Harmonic content (V and A) *	$\%$	•	•	•	15 <sup>th</sup>
Temperature	$^{\circ}C$		•		


- (•) Available through display and communications.
- (••) Only available through communications.
- (\* ) Harmonic content in HAR model.

### 1.4 Other features

- A small sized instrument with a 85x52x70mm (3 modules).
- Measurement in true effective value (TRMS).
- Instant, maximum, minimum values for each parameter.
- Energy metering function.
- 1 GW·h counter in consumed energy.
- 100 MW·h counter in generated energy.
- Backlit LCD display.
- Built in RS-485 communications (Modbus RTU®).
- Temperature probe built in the equipment.

### 1.5 Available models

CODE	REFERENCE
665010	MTDIN1
665011	MTDIN2
665012	MTDIN1HARCOM
665155	MTDIN2COM




## 2 INSTALLATION AND START-UP

This manual contains information and warnings about the analyzer which must be followed to guarantee the proper operation of all instrument functions and to maintain it in a safe condition. The analyzer must not be switched on until it is finally connected to the electrical source.

If the equipment is handled in a way not specified by the manufacturer, the equipment's protection may be compromised.

When it is likely that the equipment has lost its protection (i.e. with visible damage), it must be disconnected from the auxiliary supply. In this event, contact a qualified electrical technician.

### 2.1 Installation

The following features must be taken into consideration before supplying power to the equipment:

#### 2.1.1 Power supply voltage

Power supply:	230 V <sub>ac</sub> . or 85 to 265 V <sub>ac</sub> and 95 to 300 V <sub>dc</sub>
Frequency:	50 ... 60 Hz
Power supply tolerance:	-15 ... +10%
Connection terminals:	14 - 15
Equipment consumption:	3 VA

#### 2.1.2 Maximum voltage in the voltage measurement circuit

Voltage:	300 V ~ AC. phase-neutral 520 V ~ AC. phase-phase
Frequency:	50 ... 60 Hz

#### 2.1.3 Maximum permanent current in the current circuit

In scale $I_n/1A$ :	1.2 A
In scale $I_n/5A$ :	6.0 A

#### 2.1.4 Transistor output features

Type NPN transistor:	Opto-insulated / Open Collector
Maximum operating voltage:	24 V <sub>dc</sub>
Maximum operating current:	50 mA
Maximum frequency:	5 imp / s
Impulse length:	100 ms

#### 2.1.5 Temperature probe features

The MTDIN has a built in temperature sensor. The sensor has a  $\pm 2$  °C accuracy and a temperature measurement range of -10 ... +50°C.

The interior temperature of the MTDIN has been estimated at 14.0 °C above the interior of the cabinet where it has been installed, if the cabinet has no ventilation. If the cabinet has forced ventilation then the temperature of the MTDIN is 3.5 °C higher.

#### 2.1.6 Operating conditions

Operating temperature:	-10 ... +50°C
Relative humidity:	5 to 95 % RH (without condensation)



Altitude: Up to 2000 metres

### 2.1.7 Safety

Designed for category III installations, 300 V ~ AC (EN 61010).  
 Class II double insulation for protection against electric shock.

## 2.2 Start-up

The equipment is mounted on a DIN rail 46277 (EN 50022). All connections must remain inside the electrical board.

Note that when the instrument is switched on, the terminals may be dangerous when touched and opening or removing parts may access dangerous areas. Therefore, the equipment must not be used until it is properly installed.

The equipment should be connected to a power supply circuit protected with gl (IEC 269) or type M fuses between 0.5 and 2 A. It must have an overload/short circuit switch or equivalent device in order to disconnect the equipment from the power supply system. The power supply circuit and the voltage measurement circuit are connected with a cable with a minimum diameter of 1 mm<sup>2</sup>.  
 The secondary line for the current transformer shall have a minimum diameter of 2.5 mm<sup>2</sup>.

### 2.2.1 Description of terminals

TERMINAL	TERMINAL DESCRIPTION
1	Current input AL1 - S1
2	Current input AL1 - S2
3	Current input AL2 - S1
4	Current input AL2 - S2
5	Current input AL3 - S1
6	Current input AL3 - S2
7	Transistor output RL2
8	Common transistor output
9	Transistor output RL1
10	Measurement VL3
11	Measurement VL2
12	Measurement VL1
13	Neutral V measurement
14	Power supply voltage input
15	Power supply voltage input
A	RS-485 (+)
S	RS-485 (GND)
B	RS-485 (-)



## 2.2.2 Connection diagrams




Figure 2. [4-wire / 3-wire - Low Voltage]

Figure 3. [2 voltage transformers - 3 current transformers]

Figure 4. [2 voltage transformers - 2 current transformers]

### 3 OPERATING MODE

When power is supplied to the **MTDIN**, the equipment will start its software interface on the screen showing the version of the firmware and its setting. After a few seconds the equipment is ready to operate and shows all available screens.

Once turned on, the power analyzer will display the programmable electrical parameters via the measurement *Set-up*. If there is no previous setting, the analyzer will display the voltage between phase and neutral for L1, L2 and L3




Figure 5. MTDIN




Figure 6. MTDIN display - LCD SEGMENTS

#### 3.1 Keypad




The keypad comprises a total of seven silicon buttons which are used to set the equipment. Some buttons have a rapid access function, i.e. entering the *Set Up* interface is not required. The rapid access key needs to be pressed to run the function.

Only three of the seven buttons may be pressed when the upper cover is down. This is because the remaining five keys have a high risk factor if they were to be accidentally pressed.

KEY	FUNCTION
reset	Starting the equipment and clearing maximum and minimum values for all instant parameters. Pressing the <i>Reset</i> key is equivalent to starting the equipment in the absence of voltage.
setup	Using a long press, after starting the equipment (in the absence of voltage, or after pressing the <i>Reset</i> key), <b>Communication Set-up</b> is accessed. Here the RS485 port parameters may be set and all communication and measurement parameters may be blocked using a password. Using a long press, after starting the equipment ( <i>runtime</i> mode), <b>Measurement Set-up</b> is accessed. Each and every parameter for measurement may be changed.
clear energy	Rapid access function; using a long press (pressed for 5 seconds), all enabled energy counters are cleared ( <i>kW·h / kvarL·h / kvarC·h / kVA·h</i> in power consumption or consumption and generation).
clear max Pd	Rapid access function; using a long press (pressed for 5 seconds), the Power demand parameter previously set in <b>Measurement Set-up</b> is





















	cleared (Power demand) ( <i>kW III / kV·A III / A III / A ph</i> ).
	Displaying all electrical variables by repeated presses, in <i>runtime</i> mode. In <i>Set-up</i> mode has the function of advancing the setting screens.
	Pressing in <i>runtime</i> mode, displays the minimum value of displayed variable/s. In <i>Set-up</i> mode it has the function of moving 1 digit sideways.
	Pressing in <i>runtime</i> mode, maximum variable values are displayed. In <i>Set-up</i> mode it has the function of increasing 1 digit cyclically (from 0 to 9), or selecting between two possible preset configurations (for example: yes or no).




### 3.2 Default settings

The **MTDIN POWER ANALYZER** has a factory setting for display, communication and measurement. For this reason and due to the fact that this default setting is not valid in nearly all cases, the user must properly set-up the display, measurement and communication in accordance with the installation's requirements.

#### 3.2.1 Default display



 <p>Figure 7. Phase-neutral voltage</p>	 <p>Figure 8. Phase-phase voltage</p>	 <p>Figure 9. Current per phase</p>	 <p>Figure 10. Active power per phase</p>
 <p>Figure 11. Reactive power per phase</p>	 <p>Figure 12. Apparent power per phase</p>	 <p>Figure 13. Power factor per phase</p>	 <p>Figure 14. % harmonic distortion in voltage per phase</p>
 <p>Figure 15. % harmonic distortion in current per phase</p>	 <p>Figure 16. PF III / Active power III</p>	 <p>Figure 17. PF III / Inductive reactive power III</p>	 <p>Figure 18. PF III / Capacitive reactive power III</p>
 <p>Figure 19. Cos φ III / Apparent power III</p>	 <p>Figure 20. Neutral current / Frequency / Temperature</p>	 <p>Figure 21. Maximum demand</p>	 <p>Figure 22. Imported / Consumed active energy</p>





### 3.2.2 LED Indicators

The MTDIN Power analyzer is supplied with two LED indicators which give information on the status

LED	FUNCTION
 CPU	The slow flashing of the LED CPU shows that the equipment has auxiliary power supply and is operative. The rapid flashing of the LED CPU shows that there is an internal problem with the start up software.
 COMM	The slow flashing of the COMM LED shows that the equipment is communicating with a master peripheral via its RS-485 communications port. The <b>MTDIN</b> Power analyzer's communications protocol is Modbus RTU.

## 4 SETTING SET-UP


The **MTDIN** Power analyzer has two very different *Set-up* configurations which can set the parameters for all the measurement and communication settings.


Measurement set-up: All the parameters of the equipment's measurements are carried out from this menu; voltage display (phase-neutral or phase-phase voltages and current transformer ratios, setting the power demand meter, setting the start page, backlight setting, returning the energy counters to zero and maximum demand, type of harmonic distortion and setting the transistor outputs.

Communication set-up: All of the analyzer's RS-485 RTU Modbus communications are programmed from this set-up menu. Also the option to enter a password to protect previous data settings in both *Set-ups* is possible from this menu.

### 4.1 Measurement Set-up

The measurement parameters for the **MTDIN** and all its functions are changed from this menu (according to type); it may start the eight energy meters and reset maximum demand (Pd), maximums and minimums recorded.

The analyzer does not store the changes to the settings until the whole setting program has been completed. If  is pressed before the end of the setting, the setting entered is not stored in the memory.

 To access MEASUREMENT Set-Up the SETUP key must be pressed for several seconds after the equipment is energized.

On entering setting mode, the message "**SETUP loc**", or as a default "**SETUP unlo**" is displayed for a few seconds indicating that it is in programming mode and it displays its status (locked or unlocked respectively).

**SETUP unlo**: on entering setting mode it is possible to view and change the setting.


**SETUP loc**: on entering setting mode it is possible to view the parameters but it is not possible to change it.


### 4.1.1 Transformation Ratios

This menu accesses the voltage and current ratios; the voltage and current primary and secondary can also be changed here.

#### 4.1.1.1 Voltage primary value

The display shows "set PriU" followed by six digits; these allow the setting of the transformer voltage primary.

To write or change the voltage transformer primary value, repeatedly press the  key increasing the value of the digit which is flashing at the time.

When the required value is on the screen, move on to the following digit by pressing , to change the remaining values.




When the last digit has been changed, press  to move back to the first digit, allowing the previously set values to be changed again. To enter the data and access the next setting process, press .




Figure 30. Voltage primary ratio

#### 4.1.1.2 Voltage secondary value

The display shows "set SecU" followed by three digits; these allow the setting of the transformer voltage secondary.

To set or change the voltage transformer secondary value, repeatedly press the  key increasing the value of the digit which is flashing at the time.

When the required value is on the screen, move on to the following digit by pressing , to change the remaining values.



When the last digit has been changed, press  to move back to the first digit, allowing the previously set values to be changed again. To enter the data and access the next setting step, press .




Figure 31. Secondary voltage ratio

#### 4.1.1.3 Current primary value

The display shows "set PriA" followed by five digits; these allow the setting of the transformer current primary.

To write or change the current primary value, repeatedly press the  key increasing the value of the digit which is flashing at the time.

When the required value is on the screen, move on to the following digit by pressing , to change the remaining values.

When the last digit has been changed, press  $\ominus_{min} \blacktriangleright$  to move back to the first digit, allowing the previously set values to be changed again. To enter the data and access the next setting step, press  $\ominus \blacktriangleright$ .



Figure 32. Current primary ratio

#### 4.1.1.4 Current secondary value

Due to the fact that the **MTDIN** Power analyzer has a double scale for measuring the current secondary, the secondary to be measured by the analyzer must be set ( $I_n / 1 \text{ A}$  or  $I_n / 5 \text{ A}$ ).

To select one of the two display measurement options, press the  $\ominus_{max} \blacktriangle$  key and the two options will alternate. Once the required secondary of current has been selected, press the  $\ominus \blacktriangleright$  key to enter the data and access the next setting step.





Figure 33. Current secondary value  $I_n / 5 \text{ A}$



Figure 34. Current secondary value  $I_n / 1 \text{ A}$

#### 4.1.2 Measurement in 2 or 4 quadrants

The **MTDIN** Power analyzer may measure in two quadrants (power consumption), or in four quadrants (power consumption and generation). If measurements are only to be taken in power consumption, the two quadrant option is recommended to avoid exported or generated energies being displayed ( $-kW \cdot h / -kvarL \cdot h / -kvarC \cdot h / -kVA \cdot h$ ).





To select one of the two display options (2 or 4 measurement quadrants), press the  key and the two options will alternate. Once the required option is selected, press the  key to enter the data and access the next setting step.



Figure 35. Measurement in 4 quadrants






Figure 36. Measurement in 2 quadrants


### 4.1.3 Power demand meter

The MTDIN power demand meter is the integration in the time of a preset instant parameter. The amplitude of this window is preset by the integration time.

#### 4.1.3.1 Integrated parameter

The display shows "Pd Code" followed by two digits which identify the code or variable to be integrated as Maximum Demand.


To select one of the four integration parameters available, press the  key and the four options will alternate in turn. Once the required option is selected, press the  key to enter the data and access the next setting step.






If "Pd Code 00" is selected, the instant integration of the power demand meter will be deactivated.

#### 4.1.3.2 Integration period

The Integration Period of the power demand meter may vary between a minimum of 1 minute up to a maximum of 60 minutes.

To write or change the integration time value, repeatedly press the  key increasing the value of the digit which is flashing at the time.

When the required value is on the screen, move on to the following digit by pressing , to allow the remaining values to be changed.

When the last digit has been changed, press  to move back to the first digit, allowing the previously set values to be changed again. To enter the data and access the next setting step, press .

### 4.1.3.3 Clearing power demand meter value



To clear or save maximum demand, press the  key and the two options will alternate. Once the required option is selected, press the  key to enter the data and access the next setting step.



Figure 41. No-clearing power demand meter value







Figure 42. Clearing power demand meter value

## 4.1.4 Display and backlight

### 4.1.4.1 Selection of screens to be displayed

Due to the fact that the **MTDIN** Power analyzer has a large number of default screens (as shown in section 3.2.1 Default display), the user has the option of setting a personalized display by the screens intended to be displayed.

The display shows as default “def page yes”; the  key has to be pressed to proceed to the personalised display option. The analyzer will show “def page no” on the screen; to enter the data and proceed to this setting, press .

Once the personalisation option has been entered, by using  key the screens shown in section 3.2.1 Default display will be displayed in turn. By using the  button, the screen to be displayed is selected. Select “yes” or “no” respectively.

### 4.1.4.2 Selection of start page




In order to select the equipment’s preferred start up screen, repeatedly press the  key up to display the screen to be selected. Once the required option is selected, press the  key to enter the data and access the next setting step.



Figure 43. Select preferred page

Rotating function: Using the rotating display function, the Power analyzer automatically displays every available screen for five seconds each.

The  must be used to enter the rotating display function when all electrical parameters are flashing at the same time.

#### 4.1.4.3 Backlight (Backlit display)

The time in which the back lighting will be on after the last use is set by using the keypad in this menu. The display is permanently on if 00 is set.

#### 4.1.5 Clearing energy meter values

Clearing energy meters refers to the four consumed or imported energy meters. To select clear these meters of  $kw\cdot h$ , press the  $\text{max}$  key and the two options will alternate. Once the required option is selected, press the  $\text{enter}$  key to enter the data and access the next setting step.



Figure 44. No-clearing energy meters



Figure 45. Clearing energy meters

#### 4.1.6 Setting THD or D

*Harmonic distortion rate* measurements may be calculated using two measurement options: the effective value or the fundamental value.

To select one of the two calculation options, press the  $\text{max}$  key and the two options will alternate. Once the required option is selected, press the  $\text{enter}$  key to enter the data and access the next setting step.



Figure 46. Harmonic distortion value for the effective value (RMS)



Figure 47. Harmonic distortion value for the fundamental value

#### 4.1.7 Digital output for the transistor

Two types of settings may be made using the MTDIN's digital transistor outputs:

- Impulse per  $n\ kW\cdot h$  or  $kvar\cdot h$  (Energy): the value for the energy consumed or generated may be set to generate an impulse.
- Alarm condition: associates a parameter to a digital output, setting a maximum, minimum and delay for the trip condition.


In the event that no condition needs to be set, the 00 code is typed and entered using the  $\text{enter}$  key.


##### 4.1.7.1 Impulse per $n\ KW\cdot h$ or $Kvar\cdot h$ consumed or generated


In order to generate an impulse for consumed  $n\ kW\cdot h$ , the energy meter to be used has to be selected:





PARAMETER	SYMBOL	CODE
Active energy III	<i>kW·h III</i>	31
Inductive reactive energy III	<i>kvarL·h III</i>	32
Capacitive reactive energy III	<i>kvarC·h III</i>	33
Apparent energy III	<i>kVA·h III</i>	44
Active energy generated III	<i>kW·h III (-)</i>	45
Inductive reactive energy generated III	<i>kvarL·h III (-)</i>	46
Capacitive reactive energy generated III	<i>kvarC·h III (-)</i>	47
Apparent energy generated III	<i>kVA·h III (-)</i>	48

Once the energy code has been selected and entered using the  key, the watts-time per impulse is entered or as a default, kilowatts-time per impulse.

For entering the watts-time rate per impulse, repeatedly press the  key increasing the value of the digit which is flashing at the time.

When the required value is on the screen, move on to the following digit by pressing , to allow the remaining values to be changed.

When the last digit has been changed, press  to move back to the first digit, allowing the previously set values to be changed again. To enter the data and access the next setting step, press .




Figure 48. Watts / impulse

#### 4.1.7.2 Alarm condition

In order to link an alarm condition to an energy parameter, the code for the selected parameter has to be entered. A list of electrical parameters and their codes is shown on the next page.



PARAMETER	PHASE	SYMBOL	CODE
Phase-neutral voltage	L1	V 1	01
Current	L1	A 1	02
Active power	L1	kW 1	03
Reactive power L/C	L1	kvarL/C 1	04
Apparent power	L1	kV·A	38
Power factor	L1	PF 1	05
% THD V	L1	THD V1	25
% THD A	L1	THD A1	28
Phase-neutral voltage	L2	V 2	06
Current	L2	A 2	07
Active power	L2	kW 2	08
Reactive power L/C	L2	kvarL/C 2	09
Apparent power	L2	kV·A	39
Power factor	L2	PF 2	10
% THD V	L2	THD V2	26
% THD A	L2	THD A2	29
Phase-neutral voltage	L3	V 3	11
Current	L3	A 3	12
Active power	L3	kW 3	13
Reactive power L/C	L3	kvarL/C 3	14
Apparent power	L3	kV·A	40
Power factor	L3	PF 3	15
% THD V	L3	THD V3	27
% THD A	L3	THD A3	30
Temperature	-	°C	41

PARAMETER	SYMBOL	CODE	PARAMETER	SYMBOL	CODE
Active power III	kW III	16	cos φ three-phase	cos φ	19
Inductive power III	kvarL III	17	Power factor III	PF III	20
Capacitive power III	kvarC III	18	Frequency	Hz	21
Active energy	kW·h	31	L1- L2 Voltage	V 12	22
Inductive reactive energy	kvarh-L	32	L2- L3 Voltage	V 23	23
Capacitive reactive energy	kvarh-C	33	L3- L1 Voltage	V 31	24
Apparent power III	kV·A III	34	Temperature	°C	41
Maximum demand	Md (Pd)	35	Maximum demand L1	Md (Pd)	35*
Current III	AIII	36	Maximum demand L2	Md (Pd)	42*
Neutral current	I <sub>N</sub>	37	Maximum demand L3	Md (Pd)	43*


\* Variables only valid if the Maximum Demand for current has been set per phase.






There are also some codes which refer to the three-phases at the same time (Function OR). If one of these variables has been selected, the alarm will go off when any of the three-phases, or all three at the same time, match the preset conditions.

PARAMETER	SYMBOL	CODE
Phase-neutral voltage	V1 / V2 / V3	90
Current	A1 / A2 / A3	91
Active power	kW1 / kW2 / kW3	92
Reactive power	kvar1 / kvar2 / kvar3	93
Apparent power	kV·A1 / kV·A2 / kV·A3	98



Power factor	PF1 / PF2 / PF3	94
Phase-phase voltage	V12 / V23 / V31	95
% THD V	Thd1 / Thd2 / Thd3 V	96
% THD I	Thd1 / Thd2 / Thd3 A	97

Once the Alarm Condition code has been selected and the data entered using the  key, the *maximum value*, *minimum value* and the *delay* in seconds for the alarm condition must be entered.

For entering the maximum, minimum and delay values, repeatedly press the  key increasing the value of the digit which is flashing at the time. When the required value is on the screen, move on to the following digit by pressing , to allow the remaining values to be changed. When the last digit has been changed, press  to move back to the first digit, allowing the previously set values to be changed again. In order to enter one of the pieces of data, press the  key. Once the delay has been set, press the  key entering the data and ending the setting.




Figure 49. Maximum value




Figure 50. Minimum value




Figure 51. Delay

Setting the second digital output is shown on the display as "Out 2". This must be set by using the settings shown below.

MIN +	MAX + max > min	<table style="width:100%; border:none;"> <tr> <td style="width:33%; text-align:center;">ON</td> <td style="width:33%; text-align:center;">OFF</td> <td style="width:33%; text-align:center;">ON</td> </tr> <tr> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> </tr> <tr> <td style="text-align:center;">0</td> <td style="text-align:center;">Min</td> <td style="text-align:center;">Max</td> </tr> </table>	ON	OFF	ON				0	Min	Max
ON	OFF	ON									
0	Min	Max									
MIN +	MAX + max < min	<table style="width:100%; border:none;"> <tr> <td style="width:33%; text-align:center;">OFF</td> <td style="width:33%; text-align:center;">ON</td> <td style="width:33%; text-align:center;">OFF</td> </tr> <tr> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> </tr> <tr> <td style="text-align:center;">0</td> <td style="text-align:center;">Max</td> <td style="text-align:center;">Min</td> </tr> </table>	OFF	ON	OFF				0	Max	Min
OFF	ON	OFF									
0	Max	Min									
MIN --	MAX +	<table style="width:100%; border:none;"> <tr> <td style="width:33%; text-align:center;">ON</td> <td style="width:33%; text-align:center;">OFF</td> <td style="width:33%; text-align:center;">ON</td> </tr> <tr> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> </tr> <tr> <td style="text-align:center;">Min</td> <td style="text-align:center;">0</td> <td style="text-align:center;">Max</td> </tr> </table>	ON	OFF	ON				Min	0	Max
ON	OFF	ON									
Min	0	Max									
MIN +	MAX --	<table style="width:100%; border:none;"> <tr> <td style="width:33%; text-align:center;">OFF</td> <td style="width:33%; text-align:center;">ON</td> <td style="width:33%; text-align:center;">OFF</td> </tr> <tr> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> </tr> <tr> <td style="text-align:center;">Max</td> <td style="text-align:center;">0</td> <td style="text-align:center;">Min</td> </tr> </table>	OFF	ON	OFF				Max	0	Min
OFF	ON	OFF									
Max	0	Min									
MIN --	MAX -- max > min	<table style="width:100%; border:none;"> <tr> <td style="width:33%; text-align:center;">ON</td> <td style="width:33%; text-align:center;">OFF</td> <td style="width:33%; text-align:center;">ON</td> </tr> <tr> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> </tr> <tr> <td style="text-align:center;">Min</td> <td style="text-align:center;">Max</td> <td style="text-align:center;">0</td> </tr> </table>	ON	OFF	ON				Min	Max	0
ON	OFF	ON									
Min	Max	0									
MIN --	MAX -- max < min	<table style="width:100%; border:none;"> <tr> <td style="width:33%; text-align:center;">OFF</td> <td style="width:33%; text-align:center;">ON</td> <td style="width:33%; text-align:center;">OFF</td> </tr> <tr> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> <td style="border-top:1px solid black; border-bottom:1px solid black;"></td> </tr> <tr> <td style="text-align:center;">Max</td> <td style="text-align:center;">Min</td> <td style="text-align:center;">0</td> </tr> </table>	OFF	ON	OFF				Max	Min	0
OFF	ON	OFF									
Max	Min	0									

Activating the outputs of the programmable values as Maximums and Minimums.

## 4.2 Communication Set-up

One or more **MTDIN** instruments may be connected to a computer or PLC in order to automate a production process or an energy control system. As well as the usual operation of each instrument, this system may centralize data at one single point; for this reason the **MTDIN** has an RS-485 communication output.



If more than one instrument is connected to one single series line (RS-485), it is necessary to assign to each a number or address (from 01 to 255) so that the central computer or PLC sends the appropriate requests to these addresses for each peripheral.

From communication *Set-up*, the **MTDIN's** communication parameters may be displayed and/or changed; this may match these parameters to the requirements of the system topologies and/or applications.

The analyzer does not store the setting changes until all of the setting has been finished. If it is *Reset* before the end of the setting, the setting entered is not stored in the memory.


☞ To access the COMMUNICATION Set-up, first press the *Reset* key and second the *Set-up* key for a few seconds.

On entering setting mode the message "SETUP inic" appears for a few seconds, informing the user that the equipment has entered communications display or setting mode.



Figure 52. Protocol information

Using this information screen, the equipment is informing the user that the Communication protocol via the RS-485 series port is standard MODBUS®.

To enter setting mode, press the  key.

### 4.2.1 Default settings

This menu option allows the automatic selection of a predefined communication parameter; the default preset parameters are: Peripheral number 1, speed 9,600 bps, parity NO, data bits 8 and stop bit 1.

If there is no need for a different preset communication setting, "no" should be selected.



To select one of the two options, just press the  key and the two options will alternate. Once the required option is selected, press the  key to enter the data and access the next setting step.




Figure 53. Non-standard communication parameters




Figure 54. Predefined communication parameters

### 4.2.2 Peripheral number

The peripheral number varies between 0 and 255 (0 and FF in hexadecimal).

To write or change the number of the peripheral, repeatedly press the  key increasing the value of the digit which is flashing at the time.

When the required value is on the screen, move on to the following digit by pressing , to allow the remaining values to be changed.



When the last digit has been changed, press  to move back to the first digit, allowing the previously set values to be changed again. To enter the data and access the next setting step, press .



Figure 55. Peripheral number

### 4.2.3 Transmission speed



The transmission speed of RS-485 communication bus may be: 1,200 bps, 2,400 bps, 4,800 bps, 9,600 bps or 19,200 bps. To select one of the transmission speeds available, press the  key and the four options will alternate in turn. Once the required option is selected, press the  key to enter the data and access the next setting step.



Figure 56. Transmission speed

### 4.2.4 Parity



Parity may be selected, even or odd; to select the type of parity, press the  key and the three options will alternate in turn. Once the required option is selected, press the  key to enter the data and access the next setting step.



Figure 57. Parity

### 4.2.5 Data bits




7 or 8 data bits may be selected; to select the number of bits, press the  key and the two options will alternate in turn. Once the required option is selected, press the  key to enter the data and access the next setting step.





Figure 58. Data bits

#### 4.2.6 Protection of data Set-up using password

This menu option aims to protect the data set in *Measurement Set-up*.

As a default the equipment does NOT protect data with the “unlo” option. By pressing the  key the data is entered and setting the equipment is finalized.

If, on the other hand, the parameters in *Measurement Set-up* are to be protected, the option “Loc” has to be selected using the  key and then the  key pressed. The protection password as a default will always be 1234; any other password code entered will be incorrect.









Figure 59. Password request to protect Set-up data



Figure 60. Enter password to protect Set-up data

For entering the password, repeatedly press the  key increasing the value of the digit that is flashing at the time.

When the required value is on the screen, move on to the following digit by pressing , to allow the remaining values to be changed.

When the last digit has been changed, press  to move back to the first digit, allowing the previously set values to be changed again. In order to enter the password, press the  key. Once the password has been set, press the  key entering the data and ending the setting.

In the event that the measurement SETUP parameters are to be changed again, the equipment has to be first unlocked by the same procedure (position “unlo”), and the appropriate changes are made.

### 5 APPENDIX – MTDIN-COM SERIES

The MTDIN Series has models capable of measuring up to the 15<sup>th</sup> harmonic in voltage and current, showing the content on the LCD display. Therefore, the HAR has a high number of display screens, where the value of the current and voltage fundamental and the content of each harmonic may be seen.

The equipment's display diagram is obtained by following the procedure on the next page.




Figure 61. Display of Harmonic Content in Voltage and Current

## 6 MODBUS RTU PROTOCOL

The **MTDIN** Power analyzer communicates using the MODBUS© protocol. In the MODBUS protocol the RTU (Remote terminal Unit) mode is used; each 8-bit per byte in a message contains two 4-bit hexadecimal characters.

The format for each byte in RTU mode is:

Code	8 bit binary, hexadecimal 0-9, A-F. 2 hexadecimal characters contained in each 8-bit field in the message.
Bits per byte	8 data bits.
Field Check-Error	CRC Type (Cyclical Redundancy Check).

Modbus functions used:

Function 01	Reading the status of the relays.
Function 03 and 04	Reading n Words (16 bits-2 bytes). Function used for reading the electrical parameters that the <b>MTDIN</b> is measuring. All electrical parameters are long with 32 bits, because of this two Words are required to request each parameter. (4 bytes - XX XX XX XX)
Function 05	Writing a relay.

### 6.1 MODBUS memory map

PARAMETER	SYMBOL	Instant	Maximum	Minimum	Units
Voltage phase	V L1	00-01	60-61	C0-C1	V x10
Current	A L1	02-03	62-63	C2-C3	mA
Active power	kW L1	04-05	64-65	C4-C5	w
Reactive power	kvar L1	06-07	66-67	C6-C7	w
Apparent power	kV·A L1	4A-4B	AA-AB	10A-10B	
Power factor	PF L1	08-09	68-69	C8-C9	x 100
Voltage phase	V L2	0A-0B	6A-6B	CA-CB	V x10
Current	A L2	0C-0D	6C-6D	CC-CD	mA
Active power	kW L2	0E-0F	6E-6F	CE-CF	w
Reactive power	kvar L2	10-11	70-71	D0-D1	w
Apparent power	kV·A L2	4C-4D	AC-AD	10C-10D	w
Power factor	PF L2	12-13	72-73	D2-D3	x 100
Voltage phase	V L3	14-15	74-75	D4-D5	V x10
Current	A L3	16-17	76-77	D6-D7	mA
Active power	kW L3	18-19	78-79	D8-D9	W
Reactive power	kvar L3	1A-1B	7A-7B	DA-DB	W
Apparent power	kV·A L3	4E-4F	AE-AF	10E-10F	w
Power factor	PF L3	1C-1D	7C-7D	DC-DD	x 100
Temperature	°C	50-51	B0-B1	110-111	°C x 10





PARAMETER	SYMBOL	Instant	Maximum	Minimum	Units
Active power III	<i>kW III</i>	1E-1F	7E-7F	DE-DF	<i>w</i>
Inductive power III	<i>kvarL III</i>	20-21	80-81	E0-E1	<i>w</i>
Capacitive power III	<i>kvarC III</i>	22-23	82-83	E2-E3	<i>w</i>
Cos $\phi$ III	<i>Cos <math>\phi</math> III</i>	24-25	84-85	E4-E5	<i>x 100</i>
Power factor III	<i>PF III</i>	26-27	86-87	E6-E7	<i>x 100</i>

Frequency	<i>Hz</i>	28-29	88-89	E8-E9	<i>Hz x 10</i>
Voltage line L1-L2	<i>V12</i>	2A-2B	8A-8B	EA-EB	<i>V x10</i>
Voltage line L2-L3	<i>V23</i>	2C-2D	8C-8D	EC-ED	<i>V x10</i>
Voltage line L3-L1	<i>V31</i>	2E-2F	8E-8F	EE-EF	<i>V x10</i>
% THD V L1	<i>%THD VL1</i>	30-31	90-91	F0-F1	<i>% x 10</i>
% THD V L2	<i>%THD VL2</i>	32-33	92-93	F2-F3	<i>% x 10</i>
% THD V L3	<i>%THD VL3</i>	34-35	94-95	F4-F5	<i>% x 10</i>
% THD A L1	<i>%THD AL1</i>	36-37	96-97	F6-F7	<i>% x 10</i>
% THD A L2	<i>%THD AL2</i>	38-39	98-98	F8-F9	<i>% x 10</i>
% THD A L3	<i>%THD AL3</i>	3A-3B	9A-9B	FA-FB	<i>% x 10</i>

Apparent power III	<i>KvaIII</i>	42-43	A2-A3	102-103	<i>w</i>
Maximum demand	<i>Md (Pd)</i>	44-45	A4-A5	104-105	<i>w/VA/mA</i>
Three-phase current (average)	<i>A_AVG</i>	46-47	A6-A7	106-107	<i>mA</i>
Neutral current	<i>In</i>	48-49	A8-A9	108-109	<i>mA</i>
Maximum demand A2	<i>Md (Pd)</i>	52-53	B2-B3	112-113	<i>mA</i>
Maximum demand A3	<i>Md (Pd)</i>	54-55	B4-B5	114-115	<i>mA</i>

		MODBUS VARIABLES			
PARAMETER	SYMBOL	Instant	Maximum	Minimum	Units
Active energy	<i>kW·h III</i>	3C-3D	9C-CD	FC-FD	<i>w·h</i>
Inductive reactive energy	<i>kvarL·h III</i>	3E-3F	9E-9F	FE-FF	<i>w·h</i>
Capacitive reactive energy	<i>kvarC·h III</i>	40-41	A0-A1	100-101	<i>w·h</i>
Apparent energy	<i>kVA·h III</i>	56-57	B6-B7	116-117	<i>w·h</i>
Active energy generated	<i>kW·h III (-)</i>	58-59	B8-B9	118-119	<i>w·h</i>
Inductive energy generated	<i>kvarL·h III (-)</i>	5A-5B	BA-BB	11A-11B	<i>w·h</i>
Capacitive energy generated	<i>kvarC·h III (-)</i>	5C-5D	BC-BD	11C-11D	<i>w·h</i>
Apparent energy generated	<i>kVA·h III (-)</i>	5E-5F	BE-BF	11E-11F	<i>w·h</i>




* Recordings available in HAR model		MODBUS VARIABLES			
PARAMETER	SYMBOL	L1	L2	L3	Units
Harmonic content in VOLTAGE		Instant	Maximum	Minimum	
RMS current	V	2AE-2AF	2CC-2CD	2EA-2EB	Vx10
Harmonic 2		2B0-2B1	2CE-2CF	2EC-2ED	%
Harmonic 3		2B2-2B3	2D0-2D1	2EE-2EF	%
Harmonic 4		2B4-2B5	2D2-2D3	2F0-2F1	%
Harmonic 5		2B6-2B7	2D4-2D5	2F2-2F3	%
Harmonic 6		2B8-2B9	2D6-2D7	2F4-2F5	%
Harmonic 7		2BA-2BB	2D8-2D9	2F6-2F7	%
Harmonic 8		2BC-2BD	2DA-2DB	2F8-2F9	%
Harmonic 9		2BE-2BF	2DC-2DD	2FA-2FB	%
Harmonic 10		2C0-2C1	2DE-2DF	2FC-2FD	%
Harmonic 11		2C2-2C3	2E0-2E1	2FE-2FF	%
Harmonic 12		2C4-2C5	2E2-2E3	300-301	%
Harmonic 13		2C6-2C7	2E4-2E5	302-303	%
Harmonic 14		2C8-2C9	2E6-2E7	304-305	%
Harmonic 15		2CA-2CB	2E8-2E9	306-307	%

* Recordings available in HAR model		MODBUS VARIABLES			
PARAMETER	SYMBOL	L1	L2	L3	Units
Harmonic content in CURRENT		Instant	Maximum	Minimum	
RMS current	A	1F4-1F5	212-213	230-231	mA
Harmonic 2		1F6-1F7	214-215	232-233	%
Harmonic 3		1F8-1F9	216-217	234-235	%
Harmonic 4		1FA-1FB	218-219	236-237	%
Harmonic 5		1FC-1FD	21A-21B	238-239	%
Harmonic 6		1FE-1FF	21C-21D	23A-23B	%
Harmonic 7		200-201	21E-21F	23C-23D	%
Harmonic 8		202-203	220-221	23E-23F	%
Harmonic 9		204-205	222-223	240-241	%
Harmonic 10		206-207	224-225	242-243	%
Harmonic 11		208-209	226-227	244-245	%
Harmonic 12		20A-20B	228-229	246-247	%
Harmonic 13		20C-20D	22A-22B	248-249	%
Harmonic 14		20E-20F	22C-22D	24A-24B	%
Harmonic 15		210-211	22E-22F	24C-24D	%



## 6.2 RS-485 Connection diagram



In the event of any equipment failure or any operational queries please contact GE's post sales service team or the local GE distributor

GE Energy  
Industrial Solutions

Industrial solutions is leading the future of electrification by recognizing today's challenges and helping to solve them. We are expanding our efforts to forge strong relationships with customers around the globe, invest in innovative ideas, and commit to technologies that will help create a cleaner, smarter and more efficient electrical infrastructure.

[www.gpowercontrols.com](http://www.gpowercontrols.com)  
[www.geindustrial.com](http://www.geindustrial.com)



GE imagination at work

MTDIN1001E  
19/10/11