



FOR ACCESSORY INSTALLATION ON J FRAMES CODE DATED ON OR BEFORE E252, PHENOLIC BLOCK MUST BE ATTACHED USING TWO FLATHEAD SCREWS ENCLOSED.