PHASE FAILURE PHASE REVERSAL RELAY (PFPR)

LINE VOLTAGE OR SEPARATE CONTROL



FOR SEPARATE CONTROL SOURCE- OMIT WIRE "A" AND WIRE "C". CONNECT SEPARATE CONTROL SOURCE TO 9 ON COIL AND TO 1 ON PFPR. WIRES "A" AND "C" ARE OMITTED AT FACTORY ON ALL STARTERS WITH A COIL VOLTAGE OF 120V OR LESS



-NOMENCLATURE-

M-LINE CONTACTOR
FU-FUSE
PFPR-PHASE FAILURE RELAY
(AGASTAT 3 PHASE QUALITY MONITOR)
(INSTRUMENT TRANSFORMERS PHASE VOLTAGE RELAY)

imagination at work

WIRING DIAGRAM
SUPPLEMENTAL, PFPR W/O O/L

AN #	THIRD ANGLE PROJECTION	SHEET #	DWG NO.	DATE	REV
09-9111		1 OF 1	55-215348	08/11/2009	6